

















SPARES AND CONSUMABLES	MAINTENANCE ROUTINE (HOURS)	TO REPLACE MFR-HDCA
<p>AC-CC</p> 	<p>1</p>   <p>EMPTY COLLECTION CHAMBER</p>	
<p>AC-DFP</p>  <p>x10</p> <p>-x10</p> <p>-x10</p>		<p>1.</p> 
<p>AC-VP</p> 	<p>10</p>  <p>INSPECT FILTERS</p> 	<p>2.</p> 
<p>AC-VL</p> 		<p>3.</p> 
<p>DP-SL3</p>  <p>x3</p>	<p>100</p>  <p>INSPECT FILTER</p> 	
<p>MFR-HDCA</p> 